



## Rescue Lip Color

**DESCRIPTION:** In this lipstick our biobased **PERFORMA™ V 150** provides needed moisturization to repair and hydrate lips, **PERFORMA™ V 343 polymer** provides high gloss.

Phase	Ingredient	Weight %	Supplier
1	Candelilla Wax	12.50	
	Cocoa Butter	12.00	
	Carnauba Wax	6.50	
	<b>PERFORMA™ V-150 biopolymer</b> INCI: pending	6.00	<b>NuCera Solutions</b>
	<b>PERFORMA™ V343 polymer</b> INCI: synthetic wax	1.00	<b>NuCera Solutions</b>
	Bis-diglyceryl polyacyladipate-2	9.00	Cremer
2	Capric/Caprylic Glyceride	19.00	Alzo International
	Jajoba Oil	21.00	
	Color Mixture	12.00	Sun Chemical
3	Vitamin E	1.00	
Color Mixture	FD&C Yellow 5 AL Lake Synthetic Wax Disp	48.00	SWD5202
	D&C Red 6 BA Lake Synthetic Wax Disp	17.00	SWD4512
	Titanium Dioxide Synthetic Wax Disp	34.85	SWD7556
	Black Iron Oxide Synthetic Wax Disp	0.15	SWD7550

### Processing Steps

- 1) Heat phase 1 to 80-85°C with moderate mixing until solution is clear.
- 2) Add phase 2 and continue mixing for 10 minutes.
- 3) Reduce heat to 75-80°C and add phase 3 while continuing to mix
- 4) Pour into lipstick mold.